



PEDAL Jumper - Plugs in-between PEDAL and OEM Harness

ABS JUMPER - Plugs in-between ABS Sensor and OEM Harness

12v -- Connects directly to the battery

FleetMAX - Display & Programming - Set vehicle top speed & calibrate unit

Two Plugs Connects ABS to Fleet and Idle

FleetMAX Connector for Display

FleetMAX Control Box

IdleMAX Control Box

IDLEMAX Relay Connector and wires
Black/White - Common
Blue/White - Normally Connected
Blue - Normally Open

LED Flashes when counting UP

LED is solid when the vehicle is moving OR the pedal is moved

LED Twinkles when the SHUTDOWN Relay is active

2 - Single Plugs - 12v power to each unit and fuses

Combined FleetMAX Enterprise & IdleMAX